

TECHNICAL BULLETIN



19 Motivation Dve Wangara, WA, 6065 AUSTRALIA
T +61 8 9302 4000 | FREE 1800 999 196 | F +61 8 9302 5000

Page 1 of 2

Date of Issue: 4/4/2016

Last revision: February 2016

File C:\Users\Conrado Concepcion\AppData\Local\Temp\WordHelper\MemCleanAC5.docx

MEM CLEAN AC5

MEM CLEAN AC5

Contains 30-60% PHOSPHORIC ACID

Danger

May be corrosive to metals.

Causes severe skin burns and eye damage

Wear protective gloves/protective clothing/eye protection/face protection.

IF SWALLOWED: Rinse mouth. Do NOT induce vomiting.

IF ON SKIN (or hair): Remove/Take off immediately all contaminated clothing. Rinse skin with water/shower.

IF IN EYES: Rinse cautiously with water for several minutes.

Remove contact lenses, if present and easy to do. Continue rinsing. Wash contaminated clothing before reuse.

IF INHALED: Remove victim to fresh air and keep at rest in a position comfortable for breathing.

Immediately call a POISON CENTER or doctor/physician.

Spills: Clean up spills immediately. Wear protective equipment.

Cover with sand, dry lime or soda ash and place in a closed container for disposal. Flush spill area with water.

Do not get water inside containers.

Additional information is listed in the Material Safety Data Sheet
IN AN EMERGENCY DIAL 000 POLICE OR FIRE



UN 1805 PHOSPHORIC ACID
CLASS 8 HAZCHEM 2R PG III



CONTENTS L
BATCH NO.



T: +61 8 9302 4000 E: sales@environex.net.au
F: +61 8 9302 5000 W: www.environex.net.au
FREE 1800 999 196 19 Motivation Drive, Wangara, WA 6065

MATERIAL & FUNCTION

MEM CLEAN AC5 is an RO Membrane cleaning solution of phosphoric acid and is used to remove protein and scale deposits left by foodstuffs, milkstone and hard water etc.

APPLICATION

It may be used in conjunction with an alkali based RO membrane cleaner such as **MEM CLEAN AS3**. **MEM CLEAN AC5** may be used where citric acid is not sufficiently effective.

DIRECTIONS FOR USE

TECHNICAL BULLETIN



19 Motivation Dve Wangara, WA, 6065 AUSTRALIA
T +61 8 9302 4000 | FREE 1800 999 196 | F +61 8 9302 5000

Page 2 of 2

Date of Issue: 4/4/2016

Last revision: February 2016

File C:\Users\Conrado Concepcion\AppData\Local\Temp\WordHelper\MemCleanAC5.docx

Corrosion resistant dosing equipment is not necessary.
The recommended injection point is into the feedwater upstream of any filtration equipment and cartridge filters.

MEM CLEAN AC5 is miscible with water in all proportions. It may be applied as the neat product, or as a solution. Mix 30L of **MEM CLEAN AC5** with 170 L hot permeate water to CIP tank. Recirculate for 4 hr, once per month..

PACKAGING 15 and 200L drums.

IMPORTANT NOTICE TO CUSTOMER

Since the use of this product is beyond the control of either seller or manufacturer, their only obligation shall be to replace any quantity of product that is proven defective. They cannot assume any risk or liability in excess of the purchase price of the product itself, which does not include labour or any consequential damages resulting from the use of this product. Determining the suitability of this product for any intended use shall be solely the responsibility of the user.

ALWAYS TEST FIRST.