

TECHNICAL BULLETIN



19 Motivation Dve Wangara, WA, 6065 AUSTRALIA
T +61 8 9302 4000 | FREE 1800 999 196 | F +61 8 9302 5000

MEM CLEAN EC3 ENZYME CLEANER FOR MEMBRANES

MEM CLEAN EC3

Contains 10-30 % Cocodiethanolamide

WARNING

Causes skin irritation.

Causes serious eye irritation

Wear protective gloves/ protective clothing/ eye protection/face protection.

IF ON SKIN: Wash with plenty of soap and water.

IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do.

Continue rinsing. If skin or eye irritation persists: Get medical advice/attention.

EMERGENCY INFORMATION: Fire: Not flammable.

Spills: Absorb onto earth or absorbant material. Transfer to clean labelled containers and dispose of according to local regulations. Additional information is listed in the Material Safety Data Sheet.

**IN AN EMERGENCY DIAL 000
POLICE OR FIRE BRIGADE**

ENZYME MEMBRANE DETERGENT

MEM CLEAN EC3 is an enzyme containing formulation for cleaning proteinaceous material from membranes.

Directions for Use: Dilute 1:10 with water and add by proportionating pump to feed water.



1 0 1 0 0 0 0 0 3

**CONTENTS L
BATCH NO.**

T: +61 8 9302 4000 E: sales@environex.net.au
F: +61 8 9302 5000 W: www.environex.net.au
FREE 1800 999 196 19 Motivation Drive, Wangara, WA 6065



MATERIAL & FUNCTION

MEM CLEAN EC3 is a proprietary protease enzyme detergent for cleaning membranes. The protease enzyme loosens food matter by partially weakening the protein structure, and the combined effect of the mild detergent and agitation will assist in dislodging the matte of food and inorganic contaminants which tend to build up on the membrane.

APPLICATIONS

TECHNICAL BULLETIN



19 Motivation Dve Wangara, WA, 6065 AUSTRALIA
T +61 8 9302 4000 | FREE 1800 999 196 | F +61 8 9302 5000

MEM CLEAN EC3 is suitable for use in cleaning most membranes utilized in the food industry.

DAIRY INDUSTRY

MEM CLEAN EC3 may be used in the cleaning cycle of dairy equipment to be cleaned by CIP. **MEM CLEAN EC3** will ensure the quick and efficient removal of protein soils.

MEM CLEAN EC3 can be used at concentrations of 0.1% to 0.3% at a temperature of up to 50°C. It should also be used in conjunction with a buffer (**MEM CLEAN 100** or **110** at about 0.5 to 1.0 %) to maintain a mildly alkaline environment. However the technical representative should consulted advice on particular conditions suited to the membrane in use.

SAFETY NOTE

MEM CLEAN EC3 is a neutral liquid containing an enzyme. Enzyme solutions may produce skin sensitivity and the aerosol may cause breathing difficulties in asthmatics. Wear goggles and rubber gloves. Operators should refer to the MSDS for safety precautions.

PACKAGING

5, 15, 200 and 1000 Litre containers.

IMPORTANT NOTICE TO CUSTOMER

Since the use of this product is beyond the control of either seller or manufacturer, their only obligation shall be to replace any quantity of product which is proven defective. They cannot assume any risk or liability in excess of the purchase price of the product itself, which does not include labour or any consequential damages resulting from the use of this product.

*Determining the suitability of this product for any intended use shall be solely the responsibility of the user. **ALWAYS TEST FIRST.***